

## Elinchrom & Sekonic Compatibility

									Compatibility from L-858D + RT-EL/PX transmitter module								
Product Category	Elinchrom Product Name	Radio System	Current / Discontinued	Channel	Group	TTL	HS	HSS	Triggering	Power Control	Power Control Level	Power Control Step	HSS	HSS command => change the mode of flash	Modeling lamp on/off	Modeling lamp by group ON/OFF	Modeling lamp power control
Compact	D-Lite RX One	Skyport-Integrated transceiver	Current	8	4 (G1 to G4)	No	No	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	D-Lite RX 4	Skyport-Integrated transceiver	Current	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	ELC 125	Skyport-Built In	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	5 F step	1/10 step	Yes	Yes	Yes	By group	Yes
	ELC 500	Skyport-Built In	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	7 F step	1/10 step	Yes	Yes	Yes	By group	Yes
	ELC Pro HD 500	Skyport-Integrated transceiver	Current	20	4 (G1 to G4)	No	No	No	Yes	Yes	7 F step	1/10 step	No	No	Yes	By group	Yes
	ELC Pro HD 1000	Skyport-Integrated transceiver	Current	20	4 (G1 to G4)	No	No	No	Yes	Yes	8 F step	1/10 step	No	No	Yes	By group	Yes
	D-Lite RX 2	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	BRX 250	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	1.3 to 5.3 F step	1/10 step	No	No	Yes	By group	Yes
	BRX 500	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	2.3 to 6.3 F step	1/10 step	No	No	Yes	By group	Yes
	Quadra Hybrid	Skyport-Built In	Discontinued	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	6.6 F step	1/10 step	No	No	Yes	By group	Yes
Continuous Light	ELM8	Skyport-Elinchrom Remorte	Current	20	4 (G1 to G4)	No	No	No	No	Yes	0,1 to 10 F Step	1/10 step	No	No	n/a	n/a	n/a
Battery Flash	ELB 400	Skyport-Built In	Discontinued	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	6.9 F step	1/10 step	No	No	Yes	By group	Yes
	ELB 500 TTL	Skyport / Phottix Odin Z	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	7 F step	1/10 step	Yes	Yes	Yes	By group	Yes
	ELB1200	Skyport-Built In	Current	20	4 (G1 to G4)	No	Yes	No	Yes	Yes	8.5 F step	1/10 step (Dial Button) 1F step (L/R Button)	No	No	Yes	By group	Yes
Receiver	EL-Skyport Receiver Plus	Skyport	Current	20	4 (G1 to G4)	No	Yes	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes
	EL Transceiver RX	Skyport	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes
	Universal Receiver Speed	Skyport	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes

									Compatibility from L-478DR-EL								
Product Category	Elinchrom Product Name	Radio System	Current / Discontinued	Channel	Group	TTL	HS	HSS	Triggering	Power Control	Power Control Level	Power Control Step	HSS	HSS command => change the mode of flash	Modeling lamp on/off	Modeling lamp by group ON/OFF	Modeling lamp power control
Compact	D-Lite RX One	Skyport-Integrated transceiver	Current	8	4 (G1 to G4)	No	No	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	D-Lite RX 4	Skyport-Integrated transceiver	Current	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	ELC 125	Skyport-Built In	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	ELC 500	Skyport-Built In	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	7 F step	1/10 step	No	No	Yes	By group	Yes
	ELC Pro HD 500	Skyport-Integrated transceiver	Current	20	4 (G1 to G4)	No	No	No	Yes	Yes	7 F step	1/10 step	No	No	Yes	By group	Yes
	ELC Pro HD 1000	Skyport-Integrated transceiver	Current	20	4 (G1 to G4)	No	No	No	Yes	Yes	8 F step	1/10 step	No	No	Yes	By group	Yes
	D-Lite RX 2	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	5 F step	1/10 step	No	No	Yes	By group	Yes
	BRX 250	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	1.3 to 5.3 F step	1/10 step	No	No	Yes	By group	Yes
	BRX 500	Skyport-Integrated transceiver	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	2.3 to 6.3 F step	1/10 step	No	No	Yes	By group	Yes
	Quadra Hybrid	Skyport-Built In	Discontinued	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	6.6 F step	1/10 step	No	No	Yes	By group	Yes
Continuous Light	ELM8	Skyport-Elinchrom Remorte	Current	20	4 (G1 to G4)	No	No	No	No	Yes	0,1 to 10 F Step	1/10 step	No	No	n/a	n/a	n/a
Battery Flash	ELB 400	Skyport-Built In	Discontinued	8	4 (G1 to G4)	No	Yes	No	Yes	Yes	6.9 F step	1/10 step	No	No	Yes	By group	Yes
	ELB 500 TTL	Skyport / Phottix Odin Z	Current	20	4 (G1 to G4)	Yes	Yes	Yes	Yes	Yes	7 F step	1/10 step	No	No	Yes	By group	Yes
	ELB1200	Skyport-Built In	Current	20	4 (G1 to G4)	No	Yes	No	Yes	Yes	8.5 F step	1/10 step (Dial Button) 1F step (L/R Button)	No	No	Yes	By group	Yes
Receiver	EL-Skyport Receiver Plus	Skyport	Current	20	4 (G1 to G4)	No	Yes	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes
	EL Transceiver RX	Skyport	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes
	Universal Receiver Speed	Skyport	Discontinued	8	4 (G1 to G4)	No	No	No	Yes	Yes	-	1/10 step	No	No	Yes	By group	Yes

**When the customer use L-858D w/ RT-EL/PX or L-478DR-EL, there are some notes as follows.**

**Please note that this compatibility table is between Sekonic light meter and receivers of each radio system. Some functions available between each radio system may NOT work with Sekonic light meters due to technical limitations.**

Item	Contents
Mode of transmitter on the camera	If using with Skyport HS, press the refresh button after you have made adjustments on the meter, and the new setting will be reflected on the Skyport HS LCD.
L-858D and L-478DR series specification	Even if the HSS mode is available on your flash units, L-858D or L-478DR series can not trigger HSS flash by radio.